

Bosch 0231.115.061 Advance Curve

Dist RPM	Low Side Advvar	High Side Advvar	Actual Advance
0	-1	1	0
250	-1	1	0
500	-1	1	0
700	-1	5	4
1000	-1	10	9
1250	6	12	11
1500	8	14	13
1750	10	16	14
2000	12	17	15
2250	14	17	16
2500	15	17	16
2750	15	17	16
3000	15	17	16
3250	15	17	16
3500	15	17	16
3750	15	17	16
4000	15	17	16

Note Rpm and Advance Degrees are in Distributor Advance to get engine Advance Double the values

Dwell ° Advance Begins
 48° 650 Distributor RPM
 1300 Engine RPM

Vacuum Retard Operation

mBar Vacuum	Retard In Distributor Degrees
25	0
50	0
75	1
100	2
125	3
150	4
175	4
200	4
225	4
250	4
275	4
300	4

