

Bosch 0231.184.004 Advance Curve

Dist RPM	Low Side Advvar	High Side Advvar	Actual Advance
0	-1	1	0
250	-1	1	0
550	-1	1	0
700	-1	4	0
1000	5	9	6
1250	6	10	7
1500	7	11	8
1750	8	12	9
2000	9	13	10
2250	10	14	11
2500	11	15	12
2750	12	16	13
3000	12	16	14
3250	12	16	14
3500	12	16	14
3750	12	16	14
4000	12	16	14

Note Rpm and Advance Degrees are in Distributor Advance to get engine Advance Double the values

Dwell

N/A Pertronix installed

Vacuum Retard Operation

mBar Vacuum	Retard In Distributor Degrees
25	0
50	0
75	1
100	2
125	3
150	4
175	5
200	5
225	5
250	5
275	5
300	5

